



AX4000RA 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	1520	Anti-Reverse Cam Spring	4264	Bail Spring Guide (B)
0041	Drive Gear Washer	1596	Bushing Washer	4266	Bail Trip Lever
0071	Rotor Nut	1676	Side Cover Screw	4267	Bail Trip Lever Washer
0080	Line Roller	2016	Drag Washer "H" (cloth)	4270	Anti-Reverse Pawl
0111	Drag Coil Spring	2257	Drag Washer "H" (blue)	4271	Anti-Reverse Cam
0345	Anti-Reverse Lever Screw	2293	Drive Gear Bushing	4274	Drag Shaft
0452	Drag Spring Washer	2346	Drag Washer "C" (cloth)	4278	Rotor
0540	Drag Click Screw	2433	Pressure Screw	4280	Bail Spring Cover
0579	Eared Washer "B"	2458	Drag Knob Screw	4281	Pinion Gear
0584	Hold Click Spring	2541	Anti-Reverse Pawl Screw	4282	Drive Gear
0787	Nut Lock Screw	2852	Handle Screw Lock	4284	Drag Knob Assembly
0792	Bearing Retainer Screw	3681	Bail Spring Guide (A)	4290	Main Shaft Assembly
0815	Line Roller Washer	3682	Bail Spring	4310	Drag Click
0940	Multi-Purpose Screw	3687	Anti-Reverse Ratchet	4357	Quick-Fire II Trigger
0949	Trigger Screw	3688	Anti-Reverse Lock Out	4379	Anti-Reverse Lever
1008	Handle Lock Washer	3692	Anti-Reverse Pawl Spring	6863	Spool Assembly
1030	Handle Assembly	3695	Oscillating Gear	6864	Bail Arm
1310	Line Roller Screw	3747	Slider Retainer Screw	6881	Bail Assembly
1442	Handle Screw Cap	3766	Oscillating Slider	6882	Side Cover
1506	Bail Spring Cover Screw	3767	Oscillating Slider Retainer	6883	Body
1511	Lever Spring	3869	Anti-Reverse Lock Out Spring		